

VOKKERO UNITY

COMHEAD

Headset Company



comhead.de | +49 40 500 580 20 | info@comhead.de

User Guide

☰ Version

1.0



This document applies to the following products:

-VOK-UNITY-EU(Ref: VO8350AAU)

-VOK-ELITE/UNITY-CHARGER (Ref: VO8363AA)

▼ TABLE OF CONTENT

TABLE OF CONTENT

PRÉAMBULE /PREAMBLE /PRÄAMBEL /PREAMBOLO

INFORMATIONS

RECOMMENDATIONS & WARNINGS

DECLARATION OF CONFORMITY

USAGE RESTRICTIONS

1. SYSTEM INSTALLATIONPROCEDURE

2. SYSTEM DESCRIPTION

2.1. VOKKERO UNITY Terminal

- [2.1.1. Description of product interface](#)
 - [2.1.2. Caractéristiques générales](#)
 - [2.2. VOKKERO UNITY Charger](#)
 - [2.2.1. Description of product interface](#)
 - [2.2.2. General Technical Specifications](#)
- [3. QUICK START OF THE CONFERENCE](#)
 - [3.1. Setting up Audio Conference](#)
 - [3.2. Description of the terminal](#)
 - [3.3. Connecting a headset](#)
 - [3.3.1. Plugging a headset](#)
 - [3.3.2. Removing the headset](#)
 - [3.4. Adjust Volume](#)
 - [3.5. Modification of the role number](#)
 - [3.6. Modification of the channel](#)
- [DOCUMENT HISTORY](#)

▼ PRÉAMBULE / PREAMBLE / PRÄAMBEL / PREAMBOLO

- Ce guide décrit les fonctionnalités du système Vokkero®, ses options et ses accessoires. Il explique comment le configurer pour permettre une communication de type conférence entre plusieurs utilisateurs.
- This guide describes the functionality of the system Vokkero®, options and accessories. It explains how to configure it to allow a conference-type communication between multiple users.
- Diese Anleitung beschreibt die Funktionalität des Systems Vokkero®, Optionen und Zubehör. Es erklärt, wie man es konfigurieren, um eine Konferenz-Art der Kommunikation zwischen mehreren Benutzern zu ermöglichen.
- Esta guía describe la funcionalidad del sistema Vokkero®, opciones y accesorios. En él se explica cómo configurarlo para permitir una comunicación de tipo conferencia entre múltiples usuarios.
- Aucun extrait de ce document ne pourra être reproduit ou transmis (sous format électronique ou papier, ou par photocopie) sans l'accord de Vokkero.

Ce document pourra être modifié sans préavis. Toutes les marques citées dans ce guide font l'objet d'un droit de propriété intellectuelle.

- No part of this document may be reproduced or transmitted (in electronic or paper, or photocopying) without the agreement of Vokkero.
This document may be changed without notice. All trademarks mentioned in this guide are the subject of intellectual property rights Vokkero.
- Kein Teil dieses Dokuments darf ohne Zustimmung von Vokkero reproduziert oder übertragen werden (in elektronischer Form oder in Papierform oder durch Fotokopieren). Dieses Dokument kann ohne vorherige Ankündigung geändert werden. Alle in diesem Handbuch genannten Marken sind Gegenstand der Rechte an geistigem Eigentum von Vokkero.
- Ninguna parte de este documento puede ser reproducida o transmitida (en fotocopias electrónico o en papel, o sin el acuerdo de Vokkero).
Este documento puede ser modificada sin previo aviso. Todas las marcas comerciales mencionadas en esta guía son el tema de los derechos de propiedad intelectual.

Systeme radiocommunication sans fil professionnel –Vokkero 

Spécialisée dans les systèmes de communication pour équipes mobiles pour les professionnels, VOKKERO® est reconnu mondialement dans le domaine sportif (leader mondial dans

 <https://www.vokkero.com/fr/>

VOGO

895 Rue de la Vieille Poste

Parc Majoria–Pompignane

Immeuble LA LÓNA,

34000 Montpellier, France

▼ INFORMATIONS

DISCLAIMER

This document and the use of any information contained therein, is subject to the acceptance of the VOKKERO terms and conditions. They can be downloaded from www.vokkero.com

VOKKERO makes no warranties based on the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice.

VOKKERO reserves all rights to this document and the information contained herein. Reproduction, use or disclosure to third parties without express permission is strictly prohibited.

Copyright © 2016, VOKKERO.

VOKKERO is a registered trademark in the EU and other countries.

TECHNICAL SUPPORT

Website

Our website contains a lot of useful information: information on modules and wireless modems, user guides, and configuration software and technical documents which can be accessed 24 hours a day.

If you have technical problems or cannot find the required information in the provided documents, contact our Technical Support on our website:

www.vokkero.com. This ensures that your request will be processed as soon as possible.

Helpful Information when Contacting Technical Support

When contacting Technical Support, please have the following information ready:

- Product type
- Firmware version (for example V1.0)
- A clear description of your question or the problem
- A short description of the application

▼ RECOMMENDATIONS & WARNINGS

All rights to this manual are the exclusive property of VOKKERO. All rights reserved. Copying this manual (without written permission from the owner) via printing, copying, recording or by any other means, translating this manual (in full or partially) into any other language, including all programming languages, using any electrical, mechanical, magnetic or optical devices, manually or any by other methods, is prohibited.

VOKKERO reserves the right to change the technical specifications or functions of its products, or to cease manufacturing any of its products, or to cease

technical support for one of its products without notice in writing and urges its customers to make sure that the information they have is valid.

VOKKERO configuration software and programs are available free of charge in a non-modifiable version. VOKKERO can make no guarantees, including guarantees concerning suitability and applicability for a certain type of application.

Under no circumstances can the manufacturer, or the distributor of an VOKKERO program, be held liable for any damage caused by the use of the aforesaid program. Program names, as well as all copyright relating to programs, are the exclusive property of VOKKERO. Any transfer, granting of licences to a third party, leasing, hire, transport, copying, editing, translation, modification into another programming language or reverse engineering are prohibited without VOKKERO's prior written authorisation and consent.

ENVIRONMENTAL RECOMMENDATIONS

All superfluous packaging materials have been eliminated. We have done everything possible to make it easy to separate the packaging into three types of materials: cardboard (box), expanded polystyrene (filler material) and polyethylene (packets, foam protective sheets). Your device is composed of materials that can be recycled and reused if it is dismantled by a specialist company. Please observe local regulations concerning the manner in which waste packaging material, used batteries and your obsolete equipment are disposed of.

WARNINGS

VOK-UNITY-EU (Ref: VO8350AAU)

VOK-ELITE/UNITY-CHARGER (Ref: VO8363AA)



Read the instructions in the manual.



CHARGER and **CONFIGURATOR** are intended for **INDOOR USE ONLY**.



The safety of this product is only guaranteed when it is used in accordance with its purpose. Maintenance should only be carried out by qualified persons.



Please note: Do not install the equipment close to a heat source or in damp conditions.



Please note: When the equipment is open, do not carry out any operations other than the ones set out in this document.



Please note: Do not open the product as there is a risk of electrical shock.



Please note: For your own safety, you must ensure that the equipment is switched off before carrying out any work on it.



Please note: For your own safety, the power supply circuit must be SELV (Safety Extra Low Voltage) and must be from limited power sources.

The product must be equipped with a switching mechanism so that the power can be cut. This must be close to the equipment. Any electrical connection of the product must be equipped with a protection device against voltage spikes and short-circuits.



Warning: If the charger is used with any other batteries or products whatsoever, there is a risk of an explosion. After use, the batteries must be disposed of at an appropriate recycling centre. They must not be thrown away to degrade in the environment. When batteries are replaced, the device must be correctly implemented.



Warning for Switzerland : the annex 4.10 of SR 814.013 Standard must be applied for batteries.



This symbol on the device or its packaging means the use of a DC voltage.

RECOMMENDATIONS REGARDING USE

- Before using the system, check that the power supply voltage shown in the user manual corresponds to your supply. If it doesn't, please consult your supplier.
- Place the device against a flat, firm and stable surface.
- The device must be installed in a location that is sufficiently ventilated so that there is no risk of internal heating and it must not be covered with objects such as newspapers, cloths, curtains, etc.
- The device must never be exposed to heat sources such as heating equipment.
- Do not place the device close to objects with naked flames such as lit candles, blowtorches, etc.
- The device must not be exposed to harsh chemical agents or solvents likely to damage the plastic or corrode the metal parts.

DISPOSAL OF WASTE BY USERS IN PRIVATE HOUSEHOLDS



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste by taking it to a collection point designated for the recycling of electrical and electronic appliances. Separate collection and recycling of your waste at the time of disposal will contribute to conserving natural resources and guarantee recycling that respects the environment and human health. For further information concerning your nearest recycling centre, please contact your nearest local authority/townhall offices, your household waste collection company or the shop where you bought the product.

▼ DECLARATION OF CONFORMITY

▼ EU

Terminals: VO8350AA, VO8350AB and VO8350AC

[https://s3-us-west-2.amazonaws.com/secure.notion-static.com/1d79d332-a06c-4272-8ed2-3fc40d2358d4/UE_Declaration_of_Conformity_Vokkero_ELITE_\(GB\)_VO8350AA_-_VO8350AB_-_VO8350AC.pdf](https://s3-us-west-2.amazonaws.com/secure.notion-static.com/1d79d332-a06c-4272-8ed2-3fc40d2358d4/UE_Declaration_of_Conformity_Vokkero_ELITE_(GB)_VO8350AA_-_VO8350AB_-_VO8350AC.pdf)

Configurator/charger: VO7674AA and VO8363AA

[https://s3-us-west-2.amazonaws.com/secure.notion-static.com/4ccb1c9a-63e6-4791-8662-e042ebfd3c93/UE_Declaration_of_Conformity_Vokkero_ELITE_\(GB\)_Configurator_-_charger_VO7674AA_-_VO8363AA.pdf](https://s3-us-west-2.amazonaws.com/secure.notion-static.com/4ccb1c9a-63e6-4791-8662-e042ebfd3c93/UE_Declaration_of_Conformity_Vokkero_ELITE_(GB)_Configurator_-_charger_VO7674AA_-_VO8363AA.pdf)

▼ UKCA

Terminals: VO8350AA, VO8250AB and VO8350AC

[https://s3-us-west-2.amazonaws.com/secure.notion-static.com/52c6009d-c1fe-4e32-ab4c-20e15d4195c7/UKCA Declaration of Conformity_Vokkero ELITE \(GB\) VO8350AA - VO8350AB - VO8350AC.pdf](https://s3-us-west-2.amazonaws.com/secure.notion-static.com/52c6009d-c1fe-4e32-ab4c-20e15d4195c7/UKCA_Declaration_of_Conformity_Vokkero_ELITE_(GB)_VO8350AA_-_VO8350AB_-_VO8350AC.pdf)

Configurator/charger: VO7674AA and VO8363AA

[https://s3-us-west-2.amazonaws.com/secure.notion-static.com/c8b72437-3178-4633-a43c-8908865e8ab8/UKCA Declaration of Conformity_Vokkero ELITE \(GB\) Configurator - charger VO7674AA - VO8363AA.pdf](https://s3-us-west-2.amazonaws.com/secure.notion-static.com/c8b72437-3178-4633-a43c-8908865e8ab8/UKCA_Declaration_of_Conformity_Vokkero_ELITE_(GB)_Configurator_-_charger_VO7674AA_-_VO8363AA.pdf)

▼ USAGE RESTRICTIONS

USE of VOKKERO UNITY in the UNION EUROPEENNE:

Some countries in the European Union do not allow all the channels available in VOKKERO UNITY. This equipment is intended to be used only inside sports arenas (Stadium...). The table below lists the channels available in the VOKKERO UNITY system and specify the associated potential usage restrictions.

Channels	Frequency (MHz)	Emission power (dBm)
S 1	869,525	27
S 2	830,25	20
S 3	830,75	20

For channels with usage restrictions, refer to appendix 1 (National Implementation) of recommendation ERC /REC 70-03 available on the ECO (European Communication Office) website:

[https://www.ecodocdb.dk/document/category/ECC Recommendations?status=ACTIVE](https://www.ecodocdb.dk/document/category/ECC_Recommendations?status=ACTIVE)

Inside the stadium, a spectrum referent may be available to assist in frequency allocation. For the use of UNITY in Europe (outside the EU), please contact

customer support: "[www.vokkero.com/Support/Technical Support](http://www.vokkero.com/Support/Technical%20Support)". In the VOKKERO HELPDESK space, log in with your identifiers (or sign up to create your account) to access the support.

The operations described below allow you to rapidly and easily implement your VOKKERO UNITY communications system.

All the operations described are valid for all the VOKKERO UNITY terminals listed below:

VOK-UNITY-EU: REF VO8350AAU

Note: Your product reference is given on the label on the back of the terminal housing.


The VOKKERO UNITY is a ready-to-use system with the following two main elements:

- **Terminals: VO8350AAU**
 - **Optional Charger: VOK-ELITE/UNITY-CHARGER: VO8363AA**
-

1. SYSTEM INSTALLATION PROCEDURE

- Connect the power unit to the end charger (if several are connected in a row).
- Connect the power unit to the mains.
- Connect the VOKKERO UNITY terminals as shown below.

Note: the order and position of the terminals on the charger(s) are not of importance.



2. SYSTEM DESCRIPTION

2.1. VOKKERO UNITY Terminal

2.1.1. Description of product interface



2.1.2. Caractéristiques générales

General Specifications	Value
Supply voltage	3.7V nominal
Maximum consumption	800mA (emission)
Terminal power supply	Lithium battery
Battery life	More than 8 hours
Charging time	4 hours from 0 to 100% battery life
Operating temperature	20°C / +55°C
Dimensions	57 x 96 x 23 mm
Weight	130g (including battery)

2.2. VOKKERO UNITY Charger

2.2.1. Description of product interface

System installation procedure :

- Connect the power supply to the charger
- Connect the power supply to the mains
- Connect the UNITY terminals as shown below. Place the terminals in the locations intended for this purpose (4 per charger). Insert them vertically so as not to damage the connector.
- When the terminal is detected, charging begins. If the corresponding LED does not come on, check that the terminal has been correctly positioned.
- To remove the terminals from the charger, pull them up.

Note: when the terminals are removed from the charger, they turn off automatically, so they must be turned on again to use them.

Be careful to use the power supply provided by Vokkero when your UNITY kit is delivered.

2.2.2. General Technical Specifications

Specifications	Value
AC/DC Power Converter (standard)	100 à 240V 12VDC/5A -50/60Hz
Operating temperature	-5°C / +40°C
Charger's dimensions	180x70x35
Charger's weight	180g
Terminal charging indicators (leds)	
-Red	No terminal or defective terminal
-Orange	Terminal charging
-Green	Terminal charged

3. QUICK START OF THE CONFERENCE

3.1. Setting up Audio Conference

The terminals are delivered pre-configured and ready-to-use.


The first step consists in turning on the terminals and in particular the Master role terminal. This role is used to synchronize the other terminals. You can recognize the Master terminal thanks to its orange icon number 1.

In case no terminal show the orange icon number 1 or if several terminals shows this orange icon number 1, that means that you have no Master or several Master roles in the network. In that case, the audio conference won't work properly. The «modification of the role number» function makes it possible to remedy this situation by offering the possibility of modifying the role number of a terminal by assigning it the role n°1 (see paragraph 3.5).

3.2. Description of the terminal

Press the On/Off button to turn on the terminal.

Press the On/Off for 3 seconds to turn off the terminal.



Note 1: all settings, including volume, remain unchanged when the terminal is turned off (i.e., will be identical when the terminal is turned again).

The LCD screen will light up indicating a number with an associated color. This number indicates the role of your device in the conference.

- Icone 1 (orange) : Master
- Icone 2 (blue) : User 2
- Icone 3 (green) : User 3
- Icone 4 (red) : User 4



Note 2: as a reminder, there must be only one Master (icon 1) in the conference

3.3. Connecting a headset

3.3.1. Plugging a headset

Plug the headset into the slot at the top of the product, beside the LCD.

Line up the 2 red marks of the product and the headset and push the connector.



Do not force the headset; it should connect easily; if this is not the case, check the headset to make sure it isn't damaged and check that you align the red dot with the red mark.

3.3.2. Removing the headset

Pull on the ring of the headset to release the connector switch.
Then remove the headset connector.



Do not attempt to remove the headset by pulling the cable.



Do not turn the connector.

3.4. Adjust Volume

Push + to increase the audio volume.
Push - to decrease audio volume.

5 steps of volume are available. A vocal synthesis (heard in the headset) indicates the step (volume 1 to volume 5).

A vocal synthesis indicates that “Minimumvolume” is reached, another vocal synthesis indicates that “Maximumvolume” is reached.

To avoid possible hearing damage, do not listen at high volume for a long time.

3.5. Modification of the role number

To function correctly, the audio conference must have a terminal with the role number

1. Your UNITY kit is delivered ready-to-use and no configuration is needed.

However, if this terminal is missing (eg: power problem or malfunction), the conference is no longer possible. The «modification of the role number» function makes it possible to remedy this situation by offering the possibility of modifying the role number of a terminal by assigning it role n ° 1.

IMPORTANT : The role numbers must be unique for the proper functioning of the conference (only one n ° 1, only one n ° 2, etc ...).

Procedure :

- Push + on the terminal for 5 seconds.
 - Your terminal screen will then display your number flashing.
 - You can switch the number by pressing + or -
 - To confirm the change of terminal role, press the “On /Off” button on the terminal.
 - After confirmation, the LCD returns to the main screen displaying the role number in a fixed way
-

3.6. Modification of the channel

UNITY offers 3 different encryption channels.

- Channel 1: **869,525 MHz**
- Channel 2: **830,25 MHz**

- Channel 3: 830,75 MHz

Know the actual channel:

To know the frequency in use, press – on the terminal for 2 seconds. A voice synthesis indicates the current channel (channel 1 to 3).

Modification of the channel:

- Push – on the terminal for 5 seconds
- A vocal synthesis announce that your entry in the modification menu «Channel Selection»
- You can switch the channel by pressing + or –
- To confirm the channel modification, press the “On / Off” button on the terminal
- After confirmation, the LCD displays the selected channel number flashing rapidly for 3 seconds before returning to the main screen.

DOCUMENT HISTORY

Version	Contents
V1.0	Creation

