

NEED MORE HELP?



C+HC Computer + Headset Company GmbH

Die Headset Spezialisten

Borsteler Chaussee 49 | 22453 Hamburg | Tel.: (040) 500 580 20

www.comhead.de

Jabra MOTION UC
Jabra MOTION UC+

Jabra[®]
YOU'RE ON

GET STARTED IN UNDER

5
MINUTES

A BRAND BY

GN Netcom

© 2013 GN Netcom A/S (North America: GN Netcom US, Inc.) All rights reserved. Jabra® is a registered trademark of GN Netcom A/S. All other trademarks included herein are the property of their respective owners. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. (Design and specifications subject to change without notice).

Made in China

MODEL: BTE6



ENGLISH.....2

DEUTSCH8

1 HOW TO CONNECT


CONNECTING WITH THE JABRA LINK 360

Plug the Jabra Link 360 into any available USB port on your PC, and open the flip boom-arm on the headset to connect.



CONNECTING WITH A BLUETOOTH DEVICE

1. While pressing the **Call** button, open the flip boom-arm. Release the **Call** button when the Bluetooth light flashes blue.
2. Wear on the ear and follow the voice-guided connection instructions.



CONNECTING WITH AN NFC DEVICE

To pair using an NFC-enabled device, refer to the online user manual.

2 HOW TO WEAR

ENGLISH

HEIGHT ADJUSTMENT


Get the perfect fit for your ear by adjusting the height of the speaker up or down.




LEFT OR RIGHT EAR WEARING STYLE

The headset can be worn on the left or right ear. To switch ear:

1. Pull the speaker all the way down.
2. Rotate the speaker 180°.
3. Twist the eargel around to fit.








3 HOW TO USE



Did you know?


You can download the User Manual at jabra.com/motionuc to learn more about additional features such as Advanced Multiuse, NFC and motion sensor interactivity. The Jabra Connect app is now available for your android or iOS device.

	On/off	Open or close the flip boom-arm
	Answer call	Open the flip boom-arm, or tap the Call button if the boom-arm is open
	End call	Close the boom-arm, or tap the Call button
	Reject call	Double-tap the Call button when there is an incoming call
	Redial last number	Double-tap the Call button when not on a call
	Adjust speaker volume	Slide a finger up/down the Volume touch-sensitive panel
	Voice commands	Tap the Voice and Mute microphone button when not on a call, until you hear 'Sagen Sie einen Befehl'. Say 'Was kann ich sagen' for a list of voice commands
	Mute microphone	Tap the Voice and Mute microphone button during a call

4 MOTION SENSOR CONTROLS

CALL ASSIST

Pick up the headset from the desk to your ear to automatically answer an incoming call.



HIBERNATION MODE

To extend battery life, the headset will enter hibernation mode when it has not been moved for 60 minutes (when Bluetooth connected) or 5 minutes (when not Bluetooth connected).



Note: Motion sensor controls are default-enabled, and can be disabled in Jabra PC Suite and/or the Jabra Connect app.


5 TRAVEL & CHARGE KIT

The Travel & Charge Kit stores and charges the headset.

CHARGING

Dock the headset and plug the dock into a power supply using the micro-USB cable or the wall charger.

Note: It takes 2 hours to fully charge the headset.



1 VERBINDEN

VERBINDEN MIT DEM JABRA LINK 360

Schließen Sie das Jabra Link 360 an einem unbelegten USB-Anschluss an Ihrem PC an und klappen Sie den Flip-Boom-Arm am Headset aus, um eine Verbindung herzustellen.



VERBINDEN MIT EINEM BLUETOOTH-GERÄT

1. Drücken Sie die Taste **Anrufen** und klappen Sie den Flip-Boom-Arm aus. Lassen Sie die Taste **Anrufen** los, wenn die Bluetooth-Kontrollleuchte blau blinkt.
2. Tragen Sie das Gerät am Ohr und befolgen Sie die sprachgeführten Anweisungen zum Herstellen der Verbindung.



VERBINDEN MIT EINEM NFC-GERÄT

Informationen zur Kopplung mit einem NFC-fähigen Gerät finden Sie in dem Online-Benutzerhandbuch.

2 TRAGEN

DEUTSCH

HÖHENANPASSUNG


Sorgen Sie für die optimale Passform für Ihr Ohr – indem Sie den Lautsprecher in der Höhe nach oben oder unten regulieren.




TRAGESTIL LINKES ODER RECHTES OHR

Das Headset kann am linken oder am rechten Ohr getragen werden. So wechseln Sie das Ohr:

1. Ziehen Sie den Lautsprecher ganz nach unten.
2. Drehen Sie den Lautsprecher um 180°.
3. Drehen Sie am Eargel, bis die optimale Passform erreicht ist.






3 VERWENDEN



Wussten Sie schon?


Weitere Informationen zu Zusatzfunktionen, wie Advanced Multiuse, NFC und zur Inaktivität des Bewegungssensors erhalten Sie im Benutzerhandbuch, das Sie unter jabra.com/motionuc herunterladen können. Die App Jabra Connect ist nun für Ihr Android- oder iOS-Gerät erhältlich.

	Netztaste (Ein/Aus)	Aus- oder Einklappen des Flip-Boom-Arms
	Anruf annehmen	Klappen Sie den Flip-Boom-Arm aus oder tippen Sie bei ausgeklapptem Flip-Boom-Arm auf die Taste Anrufen
	Anruf beenden	Klappen Sie den Flip-Boom-Arm ein oder tippen Sie auf die Taste Anrufen
	Anruf abweisen	Doppeltippen Sie auf die Taste Anrufen , wenn ein Anruf eingeht
	Wahlwiederholung	Doppeltippen Sie auf die Taste Anrufen , wenn Sie sich nicht in einem Gespräch befinden
	Hörlautstärke regulieren	Fahren Sie mit einem Finger auf dem TouchPanel Lautstärke nach oben bzw. nach unten
	Sprachbefehle	Tippen Sie auf die Taste Sprache und Mikrofon stumm schalten , wenn Sie sich nicht in einem Gespräch befinden. Halten Sie die Taste gedrückt, bis Sie die Aufforderung „Sagen Sie einen Befehl“ hören. Sagen Sie „Was kann ich sagen“, um eine umfassende Liste der Sprachbefehle zu erhalten
	Mikrofon stumm schalten	Tippen Sie während eines Gesprächs auf die Taste Sprache und Mikrofon stumm schalten

4 BEWEGUNGSSENSOR-BEDIENELEMENTE

RUFUNTERSTÜTZUNG

Nehmen Sie das Headset vom Schreibtisch auf und halten Sie es an Ihr Ohr, um einen eingehenden Anruf automatisch anzunehmen.



RUHEMODUS

Zur Verlängerung der Akkulebensdauer wechselt das Headset in den Ruhemodus, wenn es 60 Minuten lang (bei Bluetooth-Verbindung) bzw. 5 Minuten (ohne Bluetooth-Verbindung) nicht bewegt wurde.



Hinweis: Die Bewegungssensor-Bedienelemente sind standardmäßig aktiviert und können in der Jabra PC Suite und/oder der App Jabra Connect deaktiviert werden.


5 REISE- UND LADEKIT

Das Reise- und Ladekit bietet Stauraum für Ihr Headset und die Möglichkeit, Ihr Headset zu laden.

AUFLADEN

Stellen Sie das Headset in die Dockingstation und schließen Sie diese mit dem micro-USB-Kabel oder dem Wandladegerät an einer Spannungsversorgung an.

Hinweis: Nach max. 2 Stunden ist das Headset voll geladen.



C+HC Computer + Headset Company GmbH
Die Headset Spezialisten
Borsteler Chaussee 49 | 22453 Hamburg | Tel.: (040) 500 580 20
www.comhead.de