



Handling calls



Managing multiple calls



Adjusting the volume | Lautstärke einstellen | Régler le volume | Impostazione del volume | Ajustar el volumen | Ajustar o volume | Volume instellen | Ρύθμιση έντασης | Indstilling af lydstyrke | Ställ in volymer | Äänenvoimakkuuden säätäminen | Regulacja głośności | Регулировка громкости | 靈蒜 | 靈蒜 | Sesdüzeyiniayarlar | 靈 | 靈 | Mengatur volume suara | 靈 | 靈

Muting the microphone | Mikrofon stummschalten | Couper le microphone | Silenziamento del microfono | Silenciar el micrófono | Activar o modo de silêncio no microfone | Microfoon op mute schakelen | Σίγαση μικροφώνου | Frakobling af lyd på mikrofon | Stäng av mikrofonen | Mikrofonin mykistäminen | Wyciszenie mikrofonu | Отключениемикрофона | 靈 | 靈 | 靈 | 靈 | Mikrofonukapat | 靈 | 靈 | Menonaktifkansuaramikrofon | 靈 | 靈

Replacing the ear pad | Ohrpolster austauschen | Remplacer le coussinet d'oreille | Sostituzione dei cuscinetti auricolari | Cambiar las almohadillas | Substituir as almofadas | Oorkussens vervangen | Αντικατάσταση των καλυμμάτων αυτιών | Udskitning af ørepolstringer | Byt øronkuddar | Korvarehmusteiden vaihto | Wymiana poduszek słuchawkowych | Заменаподушекамбушоро | 靈 | 靈 | 靈 | 靈 | Kulakyastiğinindeğiştirilmesi | 靈 | 靈 | 靈 | 靈 | Mengganti Bantalan Telinga | 靈 | 靈 | 靈 | 靈

Cleaning the product | Produkt reinigen | Nettoyage du produit | Pulizia del prodotto | Limpeza del producto | Limpar o produto | Het product reinigen | Καθαρισμός του προϊόντος | Rengöring af produktet | Rengöra produkten | Tuotteen puhdistus | Czyszczenieproduktu | Чисткапродукта | 靈 | 靈 | 靈 | 靈 | Ürünün temizlenmesi | 靈 | 靈 | Membersihkan produk | 靈 | 靈

