plantronics.

Savi® W440-M™ Quick Setup Guide

Welcome:

Using a Plantronics Savi headset for PC calls will deliver a simpler, more comfortable and better sounding audio experience than you could get using just your computer's internal microphone and speaker.



Savi W440-M Key Features:

- One-touch call answer/end, vol+/-, mute for PC calls
- Lightest DECT™ wireless headset on the market
- Multitask, hands-free up to 300 feet
- Hot swappable battery for unlimited talk time (additional battery sold separately)
- Voice-dedicated DECT technology eliminates Wi-Fi interference
- Noise-canceling microphone filters out background noise



Getting started:

The Plantronics Savi headset is ready to use with your computer and **Microsoft® Lync™**.

 Connect your USB adapter to the computer. If this is the first time you are connecting, wait for the installation process to complete. Restart the computer if directed to do so.

Configuring Microsoft Lync to always route call audio to the headset:


- 2. Click on the drop down on the right side of the main Microsoft Lync window.
- 3. Select the Audio Device option.
- 4. Choose your Plantronics headset for *Audio Device*.
- 5. Check the Also Ring box for Secondary Ringer and choose your PC speakers from the drop down menu if you would like them to ring for incoming calls.
- 6. In this screen you can also test and adjust volumes.
- 7. Click **Ok** when finished.


Note: USB configuration settings are unique for each USB port. If you connect the headset to a different port you will need to make these changes again to set behavior for that USB port.



C+HC Computer + Headset Company GmbH Die Headset Spezialisten

Borsteler Chaussee 49 | 22453 Hamburg | Tel.: (040) 500 580 20 www.comhead.de





Making and Receiving Calls with Microsoft Lync

To MAKE a call:

To call an existing contact, click on the drop down next to their name (1) and select the number you would like to call (2).

You can also enter a phone number manually using the search box located at the top of the main Microsoft Lync screen (3).

When a call is placed, a call window will open and the audio will be routed to your headset.

To RECEIVE a call:

When you receive a call, a notification window will appear in the lower right corner of your computer screen (4).

To answer the call, use the controls on your headset or click on the call notification window (5).

To **REDIRECT** a call:

You can also redirect a call by clicking **Redirect** (6) and choosing one of the options given.

